

Cleaning & Disinfecting Your Lottery Terminal

Step 1: Follow These Guidelines



Power OFF the terminal **BEFORE** you begin cleaning or disinfecting



If surfaces are dirty, they should be cleaned prior to disinfecting



Always wear gloves when working with cleaning solutions and disinfectants



Do NOT get liquids inside the unit!

If liquids get inside the unit, **call the Hotline at 1-800-692-7353** to have a qualified technician determine if it is safe to power the unit back on.

Step 2: Choose Correct Supplies

Approved Cleaning Materials

- Clean, non-abrasive cloths

DO NOT USE:

- Cloths with steel threads
- Sponges with abrasive
- Steel wool
- Steel blades



Approved Disinfecting Liquids

- **Isopropyl alcohol 70%** concentration is the only disinfectant approved by Scientific Games for all touch screens and terminals

DO NOT USE:

- Isopropyl alcohol stronger than 70%
- Methyl or ethyl alcohol
- Paint thinner
- Benzene
- Alkali lye
- Acid
- Bleach (including Clorox Wipes)
- Detergents containing fluoride
- Detergents containing ammonia at concentration greater than 1.6%
- Detergents containing abrasives
- 409



Step 3: Clean & Disinfect

If your terminal is visibly dirty:

1. Dampen a clean, non-abrasive cloth with a mild soap-and-water solution. Squeeze out any excess moisture from the cloth.



2. **DO NOT SPRAY OR APPLY ANY CLEANING SOLUTION DIRECTLY ON THE TOUCH SCREEN.** Instead, apply solution onto the cloth, then wipe with the cloth.

3. Clean the surfaces and allow them to dry.

To disinfect the terminal:

1. Dampen a new clean, non-abrasive cloth with disinfectant. Squeeze out any excess moisture from the cloth.




2. **DO NOT SPRAY OR APPLY ANY DISINFECTANT DIRECTLY ON THE TOUCH SCREEN.** Instead, apply solution onto the cloth, then wipe with the cloth.

3. Disinfect the surfaces and allow them to dry.

Cleaning & Disinfecting Your Lottery Terminal

Countertop Terminals



Vending Machines

